

This quick start guide is only meant for the doorlock at factory state

Make sure the doorlock is powered with battery. If it is not, use key to open the door then put in the battery.(need 4 X AA batteries)

Step 1. Put your finger at the recognition panel.

Step 2. Press # at the lower right corner

Step 3. Press # again and place the finger at the recognition panel. You need to input the fingerprint 3 times for confirmation purpose. If you would like to skip this step, press # directly without input the fingerprint to enter the password setting.

Step 4. Enter the password(6 digits) and press # to confirm. Input the same password again for confirmation purpose and press #. If you key in one digit wrongly, press \* to delete this digit.

Step 5. Press \* repeatedly to exit system settings.